

Clutch

Engagement of the clutch allows for power transfer from the engine to the transmission and eventually to the drive wheels. Disengagement of the clutch provides the necessary halt of power transfer that allows the engine to continue running while no power is supplied to the drive wheels.

www.youtube.com/watch?v=6BaEAbapRg

